



2005-07 Quarter Window Louvers installation Instructions



Component List:

- Passenger Side Louver with 3M adhesive (preassembled)
- Driver Side Louver with 3M adhesive (preassembled)

Tools Required:

- Isopropyl Alcohol
- Masking Tape

MRT does NOT warranty any installation and will not be responsible for any improper installs!

READ ALL INSTRUCTIONS PRIOR TO INSTALLING!!

Test fit louvers before painting if possible.

Installation:

1. Verify the bonding tape surface has not been damaged during the painting process. If tape is damaged, it must be replaced with 3M acrylic bonding tape for proper adhesion. **(3M acrylic tape part # 051131-06382)**
2. Thoroughly clean around the window with isopropyl alcohol to remove any grease and wax.
3. Place louver in desired location and mark the corners with masking tape. Do NOT stick to the window yet!
4. Once the desired location has been marked and when the temperature is above 70° F, peel back the red backing from the 3M tape, and carefully put the louver on the window.
5. Press firmly around the edges, where the tape was, to insure good adhesion.
6. Wait 36-48 hours before car is washed or exposed to rain. This will help insure maximum adhesion from the 3M acrylic.

NOTE: We recommend having your louvers painted by a professional automotive painting facility to insure paint quality and consistency with your vehicle.