

**2010+ Model – Pre-Installation Modification – Relocate the Sound Tube Canister:**

1. Raise hood and prop open. Remove the Bolt (13mm) that secures the module to the fender. Remove the factory U-Nut from the fender flange (SAVE FOR REUSE).



3. Remove the metal bushing from the rubber isolator by lifting up.



4. Remove the rubber isolator from the Canister and cut out 1/2" from the center of the isolator, as shown below. Replace the isolator halves onto the top side of canister bracket. Insert the metal bushing into isolator from the bottom side, as shown below.



5. Install the canister to the **BOTTOM SIDE** of the fender flange using the factory bolt and U-Nut

